

Warrick Series 2 Conversions to Series 16 Open Board

The Series 2 relay was a solid-state relay with field adjustable sensitivity. It is now obsolete but if you know the sensitivity you are using then you can replace it with a Series 16 Open Board relay using the chart below. This will come with the retrofit option so it fits within the same footprint as the Series 2 relay. Review the Series 2 p/n structure below to find your sensitivity option. The p/n's below use an 'X' as a place holder for direct mode and a 'Y' for inverse mode. Replace those with the sensitivity option you had on the Series 2 p/n. See Sensitivity Chart.

Mode Series 2 P/Ns	Direct Mode	Inverse Mode	
2C1F0	16X1D0R	16Y1D0R	
2C2F0	16X2D0R	16Y2D0R	
2C4F0	No 460 VAC Option	No 460 VAC Option	
2C5F0	No 575 VAC Option	No 575 VAC Option	
Option 'C' has two N.O. contacts, second 16 may be required			
2D1F0	16X1D0R	16Y1D0R	
2D2F0	16X2D0R	16Y2D0R	
2D4F0	No 460 VAC Option	No 460 VAC Option	
2D5F0	No 575 VAC Option	No 575 VAC Option	
2E1F0	16X1D0R	16Y1D0R	
2E2F0	16X2D0R	16Y2D0R	
2E4F0	No 460 VAC Option	No 460 VAC Option	
2E5F0	No 575 VAC Option	No 575 VAC Option	
Option 'E' has two N.C. contacts, second 16 may be required			
2F1F0	16X1D0R	16Y1D0R	
2F2F0	16X2D0R	16Y2D0R	
2F4F0	No 460 VAC Option	No 460 VAC Option	
2F5F0	No 575 VAC Option	No 575 VAC Option	
Option 'F' has three N.O. contacts, three 16VMs may be required			
2G1F0	16X1D0R	16Y1D0R	



2G2F0	16X2D0R	16Y2D0R		
2G4F0	No 460 VAC Option	No 460 VAC Option		
2G5F0	No 575 VAC Option	No 575 VAC Option		
Option 'G' has 2 N.O. contacts and 1 N.C. contact, three 16VMs may be required				
2H1F0	16X1D0R	16Y1D0R		
2H2F0	16X2D0R	16Y2D0R		
2H4F0	No 460 VAC Option	No 460 VAC Option		
2H5F0	No 575 VAC Option	No 575 VAC Option		
Option 'G' has 1 N.O. contact and 2 N.C. contacts, three 16VMs may be required				
2J1F0	16X1D0R	16Y1D0R		
2J2F0	16X2D0R	16Y2D0R		
2J4F0	No 460 VAC Option	No 460 VAC Option		
2J5F0	No 575 VAC Option	No 575 VAC Option		
Option 'J' has three N.C. contacts, three 16VMs may be required				

Sensitivity Chart				
Series 2 Sensitivity	Series 16 Direct Replace 'X' with Below	Series 16 Inverse Replace 'Y' with Below		
A	A	K		
В	A	K		
C	A	K		
D	A	K		
E	В	L		
F	C	M		
G	D	N		
Н	Е	P		

